



NOTES:

1. SLOPE SLAB 1/8" PER FOOT TOWARDS DRAIN.
2. PROVIDE 1" GAP WHERE A FLEXIBLE MECHANICAL COUPLING IS INSTALLED.
3. ALL VALVES SHALL OPEN LEFT.
4. 2" DRAIN SHALL BE INSTALLED ON BOTH SIDES OF CHECK VALVE AND ALTIITUDE CONTROL VALVE.
5. BUTTERFLY VALVES WILL BE USED ONLY IF DIAMETER OF STEEL PIPING IS 20" OR GREATER. OTHERWISE GATE VALVES WILL BE INSTALLED.
6. SIZE OF STEEL PIPING SHALL BE DETERMINED BY ENGINEER.

DD-903-07

SAN ANTONIO WATER SYSTEM
SAN ANTONIO, TEXAS



APPROVED:
MARCH 2011

SHEET
1 OF 1

ALTIITUDE VALVE PIPING - PLAN VIEW

REVISED: