



2021 METER READING SERVICES PROGRAM
Solicitation Number: R-21-002-JP

ADDENDUM 1
May 7, 2021

To Respondent of Record:

CHANGES TO THE RFQ

1. **ATTACHMENT 4:** The previous Attachment 4 is replaced with the revised Attachment 4 attached to this Addendum.
2. **ATTACHMENT 5:** The previous Attachment 5 is replaced with the revised Attachment 5 attached to this Addendum.

END OF ADDENDUM

This Addendum, including this one (1) page, is three (3) pages with attachments in its entirety.

ATTACHMENT:

Attachment 4, File Layout for Data SAWS Transmits to the Contractor

Attachment 5, File Layout for Data Contractor Transmits to SAWS

**ATTACHMENT 4
FILE LAYOUT FOR DATA SAWS TRANSMITS TO THE CONTRACTOR**

Field Name	Start	Length	End	Value
Workset ID (Route)	1	4	4	
Data Collection Type	5	1	5	1
WorkSet.ScheduledReadDate	6	10	15	
WorkSet.CriticalReadDate	16	10	25	
WorkSet.Cycle	26	2	27	
Customer.FullName	28	40	67	
Customer.FullStreetAddress	68	54	121	
Customer.StreetNumber	122	5	126	
Customer.StreetName	127	48	174	
Customer.Suite	175	16	190	
Customer.AccountNumber(SLID)	191	6	196	
Customer.CustomerMessage	197	40	236	
Meter.SpecialMessage	237	40	276	
MeterSessionInput.ReadMethod	277	1	277	3
Meter.MeterNumber	278	10	287	
Meter.MeterCategory	288	1	288	4
Meter.InstructionLocationCode1	289	2	290	
Meter.InstructionLocationCode2	291	2	292	
Meter.InstructionLocationCode3	293	2	294	
MeterSessionInput.NumberDials	295	1	295	
MeterSessionInput.NumberDecimals	296	1	296	0
MeterSessionInput.ReadTypeCode	297	2	298	
Meter.UtilityMeterSequenceNumber	299	6	304	
MeterSessionInput.PreviousRead	305	6	310	
MeterSessionInput.ConsecutiveEstimates	311	1	311	
MeterSessionInput.Hi1	312	6	317	
MeterSessionInput.Hi2	318	6	323	
MeterSessionInput.Low1	324	6	329	
MeterSessionInput.Low2	330	6	335	
Meter.BillCode	336	1	336	
Meter.SpecialMessageIndicator	337	1	337	
MeterSessionInput.TypeOfValidationIndicator	338	1	338	
Meter.MeterType	339	2	340	
MeterSessionInput.TextPrompt	341	2	342	
Meter.PoleNumber	343	5	347	

**ATTACHMENT 5
FILE LAYOUT FOR DATA CONTRACTOR TRANSMITS TO SAWS**

Field Name	Start	Length	End
WorkSet.WorkSetID(Route)	1	4	4
WorkSet.Cycle	5	2	6
Customer.AccountNumber(SLID)	7	6	12
Meter.MeterNumber	13	10	22
Meter.InstructionLocationCode1	23	2	24
Meter.InstructionLocationCode2	25	2	26
Meter.InstructionLocationCode3	27	2	28
Meter.UtilityMeterSequenceNumber	29	6	34
Meter.CustomDataField.CustomData	35	10	44
Meter.CustomDataField.ChangedCustomData	45	10	54
MeterChangedFields.ChangedInstructionLocCode2	55	2	56
MeterChangedFields.ChangedInstructionLocCode3	57	2	58
MeterChangedFields.ChangedInstructionLocCode1	59	2	60
MeterChangedFields.SpecialMessageChangedFlag	61	1	61
MeterChangedFields.ChangedSpecialMessage	62	10	71
MeterChangedFields.ChangedSpecialMessageInd	72	1	72
GPSInformation.ChangedLatitude	73	10	82
GPSInformation.ChangedLongitude	83	12	94
MeterSessionInput.ReadMethod	95	1	95
MeterSessionInput.ReadTypeCode	96	2	97
Meter.MeterType	98	2	99
MeterSessionInput.TextPrompt	100	2	101
MeterSessionOutput.Read	102	6	107
MeterSessionOutput.ReadDateTime	108	19	126
MeterSessionOutput.Latitude	127	10	136
MeterSessionOutput.Longitude	137	12	148
MeterSessionOutput.SkipCode	149	2	150
MeterSessionOutput.TroubleCode1	151	2	152
MeterSessionOutput.TroubleCode2	153	2	154
MeterSessionOutput.DataCollectorUserID	155	10	164